

IronWeave Carpet Tiles

CARE & MAINTENANCE

GENERAL MAINTENANCE:

1. IronWeave requires no special equipment or cleaning products..
2. To keep facilities looking clean and inviting, IronWeave tiles should be vacuumed daily.
3. Spills should be removed immediately with an absorbent cotton cloth and clean water.
4. Periodic maintenance should be performed, as needed using a hot water extraction-cleaning machine.

IronWeave has bitumen backing so water will not penetrate or harm the tiles.

NOTE: The performance and guarantee of the products used in preparation, testing, installation and maintenance of IronWeave Carpet Tiles, during and after installation, remain with the manufacturer of said product and not Langhorn Flooring Concepts, Inc. (LFCI).

RUBBERFLEX
SPECIALTY FLOORING

LANGHORN FLOORING CONCEPTS, INC.

321 S. MAIN STREET #356

SEBASTOPOL, CA 95472

info@langhornfci.com • 1-707-823-4455